

General Guidance for Testing Reactors Inside Water Cooler Systems: **Field Applications**

This document provides a protocol for testing the microbiological effectivity of Klaran WS Series UVC LED Retrofit Kit and Klaran WR Series UVC LED Reactor that has been installed in water cooler systems.

Disinfecting the Water Cooler System

- 1 Disinfect cooler with six to seven percent hydrogen peroxide (H₂O₂). Let it sit for 10 minutes and then rinse thoroughly with clean water.
- 2 The rinse water should be cultured to ensure it is not a source of contamination.
- 3 Connect the disinfected cooler to a water line.

Sampling Water from Water Cooler System for Microbial Tests

- 1 Take sample from all fittings (connectors, valves, etc.) and pump mechanism; culture the samples as a quality control for microbial contamination.
- 2 To minimize cross contamination when collecting water cooler system samples, obtain samples from longest paths first (e.g. Carbonated then chilled then ambient).
- 3 Flush with test water first when changing to a different pathway (e.g. when changing from sampling carbonated to chilled) to minimize carryover effect. Timing is important and you must understand the capacity of the tank and the pathway length to calculate volume and determine the timing between flushing and taking samples.
- 4 Obtain controls from the tank. If sampling for Pseudomonas, sampling and processing should preferably be done in the dark to contain photolyase activity (self-healing induced by visible light).
- 5 Process samples and incubate as required. Processing of samples is guideline and protocol specific. For instance, for EU, refer to EU guidelines (Council directive 98/83/EC) when sampling for Pseudomonas, Enterococcus, Coliforms, E. coli and HPC at 22°C and 37°C (three to seven days of incubation).
- 6 Record the results and analyze to confirm if the drinking water is within the standards (refer to local or regional standards).

Note: If transporting microbiology samples to an outside lab or from the field, please transport on ice. Refer to protocols, microbiological SOPs or regulatory standards for recommended media used for target microorganism, sample processing details, incubation temperature and duration.

As a plug-and-play unit, the Klaran WS Series UVC LED Retrofit Kit offers the possibility to easily perform UV-off sampling in addition to UV-on sampling by disconnecting the reactor from its power supply. Please reach out to your local Crystal IS Application Engineer for more details and additional UV-off sampling protocol recommendations.

FOR ADDITIONAL QUESTIONS ABOUT TESTING, PLEASE CONTACT [SUPPORT@CISUVC.COM](mailto:support@cisuvc.com).

DISCLAIMER

The information in this document has been compiled from reference materials and other sources believed to be reliable, and given in good faith. No warranty, either expressed or implied, is made, however, to the accuracy and completeness of the information, nor is any responsibility assumed or implied for any loss or damage resulting from inaccuracies or omissions. Each user bears full responsibility for making their own determination as to the suitability of Crystal IS products, recommendations or advice for its own particular use. Crystal IS makes no warranty or guarantee, express or implied, as to results obtained in end-use, nor of any design incorporating its Products, recommendation or advice.

Each user must identify and perform all tests and analyses necessary to ensure that its finished application incorporating Crystal IS' products will be safe and suitable for use under end-use conditions. Each user of devices assumes full responsibility to become educated in and to protect from harmful irradiation. Crystal IS specifically disclaims any and all liability for harm arising from buyer's use or misuse of UVC devices either in development or end-use.

WE INVITE YOU TO LEARN MORE ABOUT OUR UVC LEDs.



70 Cohoes Avenue, Green Island, NY 12183 U.S.A.
518.271.7375 | www.cisuvc.com | sales@cisuvc.com